
FRONT PARK ASSIST SENSOR SUPPLY
FRONT PARK ASSIST SENSOR GROUND
PARK ASSIST SIGNAL 1
PARK ASSIST SIGNAL 2
C1
C13
C3
C4
X702 20 GY/LB
X751 20 GY
D702 22 WT/YL
D705 22 WT/OR
7
8
1
2
7
8
1
2
X702 20 GY/LB
X751 20 GY
D702 20 WT/YL
D705 20 WT/OR
1
2
3
1
2
3
FRONT PARK ASSIST SENSOR SUPPLY
FRONT PARK ASSIST SENSOR GROUND
PARK ASSIST SIGNAL 1
SENSOR-PARK ASSIST 1
FRONT PARK ASSIST SENSOR SUPPLY
FRONT PARK ASSIST SENSOR GROUND
PARK ASSIST SIGNAL 2
SENSOR-PARK ASSIST 2


PARK ASSIST SIGNAL 3
C5
D706 20 WT/TN
3
3
PARK ASSIST SIGNAL 4
C10
D707 20 WT/LG
4
4
D707 20 WT/LG
1
2
3
FRONT PARK ASSIST SENSOR SUPPLY
FRONT PARK ASSIST SENSOR GROUND
PARK ASSIST SIGNAL 3
SENSOR-PARK ASSIST 3
1
2
3
FRONT PARK ASSIST SENSOR SUPPLY
FRONT PARK ASSIST SENSOR GROUND
PARK ASSIST SIGNAL 4
SENSOR-PARK ASSIST 4


MODULE-
PARK
ASSIST
PARK
ASSIST
SIGNAL
5
PARK
ASSIST
SIGNAL
6
C11
C12
C3
D708
20
WT/LB
D709
20
WT/BR
5
6
C113
5
6
S156
S155
1
2
3
1
2
3
FRONT
PARK
ASSIST
SENSOR
SUPPLY
FRONT
PARK
ASSIST
SENSOR
GROUND
PARK
ASSIST
SIGNAL 5
SENSOR-
PARK
ASSIST 5
FRONT
PARK
ASSIST
SENSOR
SUPPLY
FRONT
PARK
ASSIST
SENSOR
GROUND
PARK
ASSIST
SIGNAL 6
SENSOR-
PARK
ASSIST 6